

WINNER

trailers

hire ● sales ● parts

Designed to be used on trailers with a perforated decking, allowing a full choice of location points, the wheel strap system is a safe and reliable method of attaching vehicles to car transporter trailers.

- 1) Locate the claw hook through the deck, either in front of or behind the vehicle wheel.
- 2) The long strap section should then be fed behind the vehicles tyre and around the top section of the wheel.
- 3) Ensure that the 'link' section of the strap is positioned horizontally on the outside of the wheel.
- 4) Locate the ratchet machine on the opposite side of the wheel to the claw hook and feed the strap "loose end" through the ratchet machine drum.
- 5) Wind strap onto drum, allowing at least one full "wrap" on drum before tension is taken up.
- 6) Tension strap system ensuring that all elements remain in place.
- 7) Lock the ratchet handle down.

